



526 - Subaru Vacuum Tee Kit Instructions



SPECIAL NOTES:

- The use of a factory service manual is highly recommended. These can be purchased at the dealer, or downloaded online at <http://techinfo.subaru.com>
- Company23 is not responsible for damage done to your vehicle as a result of misuse of this product.
- Company23 does its best to ensure the accuracy of this manual but is not responsible for errors.

INSTRUCTIONS:

Step 1) **On Legacy GTs or 08-14 WRX**, remove your intercooler (see factory service manual or other guide). Locate the stock tee near the center rear of the intake manifold.

For all other applicable models, it is not necessary to remove the intercooler. On these models, the stock tee is in between and behind the alternator and power steering pump

Step 2) Pull the lines off the stock tee and install your new barbed tee. Use the provided cable ties to secure the lines to the tee. We recommend you also cable tie the other end of the intake manifold line to the intake manifold. A fourth cable tie is included for this purpose.



For questions & comments please contact sales@company23.com